




# Active A/V Network & IR Emitter

## Cable Instructions


### Active A/V Network & IR Emitter Cable Instructions

The supplied Active A/V Network cable and IR Emitter cable (Models WT-46807, WS-55807, WS-65807) or 3 IR Emitter cables (Models WS-55857, WS-55907, WS-65857, WS-65907) have a ferrite core attached to their end. The proper connection of the appropriate cable is necessary to comply with Part 15 of the FCC rules for Class B digital devices. It is important that the appropriate cable be properly connected if the Active A/V Network or the System 4 Home Theater IR Control feature of the TV is used. See page 22 of the Owner's Guide for more information on connecting the Active A/V Network or the System 4 Home Theater IR Control.

Models WT-46807, WS-55807, WS-65807



Models WS-55857, WS-65857, WS-55907, WS-65907



If this cable requires replacement, please reorder part number 975D146001 by calling (800) 553-7278.

If this cable requires replacement, please reorder part number 975D147001 by calling (800) 553-7278.

**IMPORTANT**  
Please plug the single-wire cable into the Active A/V Network terminal.